



PCA.18: PC STEALTHSTICK ATOMIC

Compatible Windows® version WIN98®/2000®/ME®/XP®

USER MANUAL

System Requirement

- 1) Support USB port
- 2) Windows 98/ME/2000/XP operation system
- 3) Direct X 7.0 or higher

Products Feature

- 1) 3 special function of “Turbo”, “Clear” and “Slow”.
- 2) With Mode LED indicator (Green colour), “Turbo” LED indicator (Red colour), “Slow” LED indicator (Red Colour).
- 3) Dual Vibration features, realistic features at different intensity control by an switch on the STEALTHSTICK ATOMIC joystick.

Operation Instruction

1) How to install the driver

- Enter Windows system, put the floppy disk to the drive then open “3.5” floppy, choose set up, following the instruction until finished.
- Double click on “My computer” - “control Panel” - “Game Controller”
- Plug the Joystick to USB port, it will detect automatically then click OK for next step, for Joystick testing can be reviewed on the properties screen.
- After testing, STEALTHSTICK ATOMIC joystick will ready for games playing .

Remarks : The USB driver program should be installed once time, the joystick will be recognized anytime .

2) How to active the “Turbo Function”

- Press Turbo and also the desired fire key you want, you will see the “Turbo LED” flashed at the same time.



www.atomic-accessories.com

info@atomic-accessories.com

4) How to clear the “ Turbo Function “

- Press clear and also desired fire key you want, you can cancelled all the function which set before.

5) How to active the “Slow Function“

- Press Slow Key once time to active the slow function, press it again to reset the slow function .

Attention!

- Don't keep it in a hot and humid place and avoid direct sunshine.
- Avoid liquid in.
- Twisting the cable is prohibited.
- Don't fixed the products on the glossy surface.
- Don't touch the metal parts.