



WIRELESS MOUSE USB ATOMIC

Mouse Wireless RF whit Scroll button.

ISTRUCTIONS MANUAL

Thecnical details:

- Mouse Wireless at RF technology. USB connector.
- Compatible PC WIN® 98SE / 2000 / ME / XP.
- Plug&Play.
- Hight resolution: 520 dpi.
- 3 keys and Scrolling button for easier Internet/menù navigation.
- Ergonomically shape.
- Wireless thecnology at radio frequency for 1.5 meters approximately.
- DC Input power 2xAAA batteries (included).

Batterys:

1. Insert two Stilo AAA batterys on the over side of the mouse.
2. Push down the cover (the mouse up side) in the arrow direction.
3. Insert batterys in the correct way and close the cover.

Caution:

1. Turn off the computer before connecting the receiver to your computer.
2. For the best performance, place the receiver at least 20cms(8 inches) away from the computer, monitor and the other devices which will cause radio interference.
3. Working on metallic surface will reduce the RF performance. Avoid placing the metallic surface.
4. Plugging or unplugging cable from Computer's USB ports improperly can cause damage to USB ports and to the computer.
5. If the working range becomes short while using, please move the receiver at Another place.

Set the ID Codes:

After installing the batteries and connecting the receiver to your computer, thurn on it . If the product doesn't works, there might be multi Products being used. To avoid interference, you may follow the procedure as below to set the ID Code.

There is an ID button on the back side is the Mouse & one on the front side of the Receiver.

1. Press the ID button on the Receiver & then on the Mouse simultaneously. The process must be completed within 20 seconds. The ID Code will set automatically.
2. After the above process the Receiver's RF Led will blink, when you move the mouse. This means the Mouse is communicating with the Receiver and is functioning successfully.
3. If you can't see the blinking LED while moving the Mouse, the Mouse hasn't Been installed successfully. Please reinstall the batteries & retey the above setup process again

Caution:

1. Please carry out the above procedures to set the ID codes again, after Replacing the Batteries or Reconnecting the Receiver. Otherwise the unit Might not function properly.
2. This product is single channel RF Mouse. If TWO units are in operation within the effective working range, radio interference will affect the performance of your input, but set the ID code to a different one which will minimize the degree of radio interence.

Use the mouse:

After successful installation, the mouse can work well with Windows® 98SE/ME/2000/XP without the need of software driver.

The mouse comes with scrolling wheel, which can function either as a wheel or as a scroll button

1. TO scroll up, move the wheel forward; to scroll down move the wheel backward.

2. To use the wheel like a standard mouse middle button, simply click (press Down) the wheel.

